

Quick Installation Guide for Lens UPGRADE PACK (Model: IN-3001)

Constituent parts of Delivery:

1x Lens (IN-3001); Quick Installation Guide (pdf download)

INSTAR Deutschland GmbH hereby ensures that you will not lose your warranty by installing this additional lens. Any damages caused by the user by faulty installation are excluded of the warranty.



Step 1: Please remove the stand and loosen the 4 screws in the back to remove the front of the camera.

YOUR INSTAR TEAM WISHES
YOU THE BEST WITH YOUR
NEW LENSE!




Step 2: Lift the cover off the camera casing and unscrew the original lens from the CMOS mount. Exchange the original lens with the new lens and turn it 4 times clockwise.



Step 3: Reconnect the camera to the powersupply and the network cable.

Now open the webinterface and turn the lens until you can see a clear and sharp picture.

Step 4: Remove the blue LED protector from the cover by carefully pushing it out from the back (Only for wide angle lenses!)



Step 5: Screw the cover back to the casing and reattach the stand.